

Ridge may be vented by holding deck and roof ridge back 1-1/2" on each side of the peak starting 12 inches from each end of the structure. Install profile filtering material to prevent insect infiltration and wind driven snow or rain. Attach ridge cap and fasten through venting material with #9 X 1-1/2" metal to wood self-drilling sealing screws. End lap ridge 6 inches and seal laps with sealant.

